

# ASSEMBLY DETAILS

These details should be read in conjunction with the setout & construction drawings provided by EZIKIT.

If you require assistance with any aspect of your installation, or would like clarification on any of these details, do not hesitate to contact us by phone, or email.

Support enquiries should be directed to:


phone: 03 6229 9733

email: [support@ezikit.com.au](mailto:support@ezikit.com.au)


(c) 2016 EZIKIT Kitform Kitchens - All Rights Reserved

This document should in no way be reproduced, distributed or supplied to another party without the expressed permission of EZIKIT.

# BASE UNITS




4 legs supplied



TYPICAL END ELEVATION

NOM	DESCRIPTION	QTY
Ⓐ	END	2
Ⓑ	BACK	1
Ⓒ	BASE	1
Ⓓ	ADJ SHELF	1
Ⓔ	RAILS	1


# CORNER BASE UNITS



CUPBOARD SPECIFIC TIPS

- Corner cupboards have a 16mm space behind. Align front edge to adjacent cupboard
- Shelf should be placed inside cupboard during assembly
- Where lazy susans are to be fitted, middle shelf is not required\*
- Refer to 'daisy catch' detail page


6 legs supplied



TYPICAL END ELEVATION

NOM	DESCRIPTION	QTY
Ⓐ	END	2
Ⓑ	BACK	2
Ⓒ	BASE	1
Ⓓ	ADJ SHELF*	1*
Ⓔ	RAILS	2

# BASE OVEN UNITS




4 legs supplied

CUPBOARD SPECIFIC TIPS

- Back to remain open to provide additional clearance & ventilation for deeper ovens
- Heat strip should be installed  
Without heat strips, warranty on doors will be void
- Induction & gas cooktops may required the oven mounted lower in the cabinet
- Some cooktops require heat barriers underneath. refer specs

front edge




shelving  
pin holes


TYPICAL END ELEVATION

NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK RAIL	1
(C)	BASE	1
(D)	ADJ SHELF	1
(E)	RAILS	1

# WALL UNITS




NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK	1
(C)	BASE	1
(D)	ADJ SHELF	1
(E)	TOP	1



TYPICAL END ELEVATION


# CORNER WALL UNITS



CUPBOARD SPECIFIC TIPS


- Shelf should be placed inside cupboard during assembly

NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK	2
(C)	BASE	1
(D)	ADJ SHELF	1
(E)	TOP	1




TYPICAL END ELEVATION

# DRAWER UNIT



## CUPBOARD SPECIFIC TIPS

- 5mm 'Euro' screws supplied for fixing runners into carcass 

NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK	1
(C)	BASE	1
(D)	RAILS	1



REFER TO INNOTECH & MULTITECH  
ASSEMBLY DETAILS FOR INDIVIDUAL  
DRAWER BOX ASSEMBLY

# INNOTECH DRAWER ASSEMBLY


## ASSEMBLY TIPS

- Always assemble on a flat surface to ensure drawer is square
- 5mm 'Euro' screws supplied for fixing runners into carcass
- Short screws supplied for assembling drawer box

NOM	DESCRIPTION	QTY
(A)	BASE (with carcass)	1
(B)	BACK (with carcass)	1
(C)	METAL SIDES (L & R)	2
(D)	FRONT CONNECTOR	2
(E)	BACK CONNECTOR (L & R) (standard only)	2
(F)	BACK CONNECTOR (L & R) (pot & pan only)	2
(G)	GALLERY RAIL (p & p only)	2
(H)	GALLERY RAIL CONNECTOR (pot & pan only)	1
(I)	RUNNERS (L & R)	2



## DRAWER ADJUSTMENT



## RUNNER ATTACHMENT

## ORDER OF ASSEMBLY

### 1) DRAWER ASSEMBLY

- Attach BACK CONNECTORS to METAL SIDES
- Screw BASE to METAL SIDES from underneath using Short Screws
- Screw BACK between BACK CONNECTORS
- Clip GALLERY RAILS to BACK CONNECTORS (Pot & Pan drawers only)

### 2) DRAWER RUNNER FITTING

- Attach RUNNER to the inside of the carcass using Euro screws


- Sit assembled drawer on top of runners and push all the way in until it clicks in place

### 3) DRAWER FRONT ATTACHMENT

- Attach FRONT CONNECTORS to Drawer Front
- Connect Drawer Front to Assembled Drawer which will click in place



# BLIND CORNER UNIT




## FINISHED COMPONENTS

NOM	DESCRIPTION	QTY
(A)	END W90 DRILL	1
(B)	DOOR	1
(C)	INFILL	1

screw through face panel as required

## CUPBOARD SPECIFIC TIPS

- ‘END W90’ panel to be screwed to rail & base behind infill line
- Infill panel C to be fixed to A from inside cupboard
- Where blind corner pull out fittings are used, the shelf is not required




## MELAMINE COMPONENTS

NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK	1
(C)	BASE	1
(D)	SHELF*	1
(E)	RAIL	1


# OVEN TOWER & MICROWAVE

## CUPBOARD SPECIFIC TIPS

- Base, Drawer & Wall units to be screwed to end panels from inside the units
- White cleat material supplied to be cut to suit oven size & screwed to end panels
- Shelf position to suit oven height. Use additional material to hold back in place if required
- If using vinyl wrapped doors, heat strips should be installed. Without heat strips, warranty on vinyl doors will be void




NOM	DESCRIPTION	QTY
Ⓐ	COLOURED END PANELS	2
Ⓑ	BASE/DRAWER UNIT	1
Ⓒ	COLOURED SHELF	1
Ⓓ	COLOURED BACK	1
Ⓔ	WALL UNIT	1
Ⓕ	OVEN/SHELF CLEAT	2




# HEAT DEFLECTOR

Heat deflectors are designed to deflect heat away from vacuum formed & other types of doors. EZIKIT recommends that they are installed alongside ovens which do not have inbuilt deflector surrounds.



Please note that if heat deflectors are not used where recommended, the warranty will be void.

# ROLLER SHUTTER TOWER




NOM	DESCRIPTION	QTY
(A)	COLOURED END PANELS	2
(B)	WALL UNIT	1
(C)	COLOURED FRAME	1
(D)	ROLLER SHUTTER KIT	1
(E)	APPLIANCE UNIT	1


CUPBOARD SPECIFIC TIPS

- Refer to roller shutter specs and installation details provided with the roller

# FRIDGE TOWER



\*alternative end




## CUPBOARD SPECIFIC TIPS

- Wall Units to be screwed to end panels from inside units
- Fix wall units so that doors will sit flush with front end of end panels
- Where fridge cavities are against a wall, the overhead cupboard may butt straight into the wall or have an infill/end panel. Refer layout drawings

NOM	DESCRIPTION	QTY
(A)	COLOURED END PANELS	2*
(B)	WALL UNIT	1


# PANTRY/BROOM UNIT

for pantry cupboards  
fixed shelf is at  
bench height



NOM	DESCRIPTION	QTY
Ⓐ	END	2
Ⓑ	BACK	1
Ⓒ	BOTTOM	1
Ⓓ	FIXED SHELF	1
Ⓔ	TOP	1

# STEP IN CORNER PANTRY



5 legs supplied


Walk in style is similar in construction without item C

NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK	2
(C)	BASE	1
(D)	ADJ SHELF	4
(E)	TOP	1

## CUPBOARD SPECIFIC TIPS



- Corner cupboards have a 16mm space behind. Align front edge to adjacent cupboard
- Bottom shelf to be placed inside cupboard during assembly

# BLIND CORNER PANTRY (Page 1 of 2)



## FINISHED COMPONENTS

NOM	DESCRIPTION	QTY
(A)	END	1
(B)	DOOR SLIDER	1
(C)	END (cavity front)	1
(D)	APRON	1
(E)	TOP	1




## MELAMINE COMPONENTS


NOM	DESCRIPTION	QTY
(A)	END	2
(B)	BACK (cavity back)	1
(C)	BACK	1
(D)	TOP	1
(E)	SHELF (fixed)	1
(F)	SHELF (adjustable)	4



# BLIND CORNER PANTRY (Page 2 of 2)





\* panels made from finished (door) material



DETAIL 2

REF DETAIL 2



REF DETAIL 2